

Installation BMW M Models



Search for a usable cable gland



Remove Rubber Grommet, feed cable from inside to the outside



Fix shorter Harness connector to Valve under the Cable gland and longer to the opposite side

Fix all with Cable ties, make sure cable has no contact to exhaust parts



Remove OE Connector from actuator and fit Module connectors between OE Connector and actuator

Assembly in opposite order to Disassembly

Functions :

- 1 Valve Open
- 2 Valve Closed
- 3 OE

These Installation instructions are a guide only, depending on year of build and car Equipment there might be slight differences to the pictures shown

Do not remove Plastic panels and covers using high force.

We will not be reliable for damages to the vehicle in case of inappropriate Installation

The use of the Valve Control Module is not legal for Road use- The use will be at your own risk.